

ADJUSTING THE AC GUARD

Our cage adjust to fit 95% of condensers, It's tube in tube construction locks in place with a set screw that is mounted on the inside frame so it can't be tampered with once unit is mounted ,Its simple as 1 2 3 you adjust it in or out,up or down to your desired height,width,or depth,and tighten your set screws. You are now ready to mount cage.

MOUNTING THE AC GUARD

There are various mounting applications based on location,pad type,pad size or no pad etc. below are the various applications.

- 1) **MOUNT ON EXISTING AC PAD** Simply set your unit in place with mounting bracket under unit on pad,scar or mark around your bracket with a marker ,remove cage ,mark your mounting holes in base plate on pad,You can tapcon directly to pad ,or use lead anchors, drill your holes,set anchors set mounting bracket in place tighten down.
- 2) **MOUNT ON ASPHALT** Use above application.
- 3) **MOUNT AROUND PLASTIC ,FIBERGLASS OR NO PAD** Simply set your unit in place,locate or mark areas where mounting base will be located,remove unit,use post hole diggers ,Dig about 14 to16 inches down,Take a bag of sacrete or ready mixed concrete put in holes wet,You will need some long bolts or screws that will fit thru holes in mounting bracket,Place your screws in mounting bracket,Set in place in wet concrete,Set your unit on brackets,Install your lock,level,leave concrete to dry.

CLICK ON LINKS TO SEE INSTALLATION VIDEO

<http://www.youtube.com/watch?v=OeQmxIDW-kY>

<http://www.youtube.com/watch?v=StYVtxvyCfU&feature=related>